

UHF Reader Config Tools Manual

Version: V1.1


2024.9.5 Revised

Contents

1. Screen function introduction	3
1.1 Setting : Parameter setting.....	3
1.2 Read : Read the settings	4
1.3 UHF/EPC : EPC/User/eTag/wTag Read and write.....	5
1.4 Test : Loop Read EPC	6

1. Screen function introduction

1.1 Setting : Parameter setting



USB Mode : USB mode settings

USB keyboard disable : No keyboard output after reading tags

HID/CDC auto send : HID/CDC automatically send data mode

COM auto send : RS232 automatically send data mode

Add Enter : Add enter at the end of data output

Add TAB : Add tab at the end of data output

Read card mode : Card reader mode settings

Auto : Check the box to enable automatic card reading

LED : Check the box to enable automatic card reading LED

Beep : Check the box to enable automatic card reading voice

Check UID : Check special cards feature is enabled

Same Card : Check the box to enable the same card check (The same card is sent only once) in accordance with the same card

Scan Time : Reading interval

Auto read UID: Check the box to enable Auto read, automatic reading EPC, data sending order/length/ format etc

Set UART Baudrate : RS232 Models adjust the communication speed


Set Wiegand : Dimensional models format

Set UHF RFID Power : Adjust power output / Reading distance

Set Frequency Range : Adjust the frequency range

1.2 Read : Read the settings

The default settings automatically read the specified region data. Main purpose is for reading TID or writing text data in the banks of EPC and USER, format and length in accordance with the requirements set.



1.3 UHF/EPC : EPC/User/eTag/wTag Read and write

